

Lens Removal Installation Instruction Sheet

Individual Fixtures

INSTALLATION INSTRUCTIONS FOR POWER FEED

Be sure to bow the lens during installation and servicing the fixture, to avoid damaging the gaskets on the endcaps. When removing the lens, use the provided suction cup in the middle of the lens to allow the lens to be bowed. Insert the lens in one end and bow the lens as shown snapping the other end in the lens retaining features. Snap in the center section of the lens to allow the end to engage the gaskets.

